



Default settings

JP1	SHORT	JP6	OPEN
JP2	SHORT	JP7	SHORT
JP3	SHORT	JP8	SHORT
JP4	OPEN	JP9	SHORT
JP5	OPEN	JP10	SHORT
	BUS		V(I/O)
JP11	SHORT		OPEN
JP12	SHORT		OPEN
JP13	SHORT		OPEN
JP14	SHORT		OPEN
JP15	SHORT		OPEN
JP16	SHORT		OPEN