



Default settings

JP1	SHORT	JP12	OPEN
JP2	SHORT	JP13	OPEN
JP3	SHORT	JP14	OPEN
JP4	SHORT	JP15	SHORT
JP5	SHORT	JP16	SHORT
JP6	SHORT	JP17	SHORT
JP7	SHORT	JP18	SHORT
JP8	OPEN	JP19	SHORT
JP9	OPEN	JP20	SHORT
JP10	OPEN	JP21	SHORT
JP11	OPEN	JP22	SHORT
	BUS	V(I/O)	
JP23	SHORT	OPEN	
JP24	SHORT	OPEN	
JP25	SHORT	OPEN	
JP26	SHORT	OPEN	
JP27	SHORT	OPEN	
JP28	SHORT	OPEN	
JP29	SHORT	OPEN	
JP30	SHORT	OPEN	
JP31	SHORT	OPEN	
JP32	SHORT	OPEN	
JP33	SHORT	OPEN	
JP34	SHORT	OPEN	
JP35	SHORT	OPEN	
JP36	SHORT	OPEN	
	CLK0	CLK5	
JP37	SHORT	OPEN	
	CLK1	CLK6	
JP38	SHORT	OPEN	