

Default settings

JP1	SHORT	JP9	OPEN
JP2	SHORT	JP10	OPEN
JP3	SHORT	JP11	SHORT
JP4	SHORT	JP12	SHORT
JP5	SHORT	JP13	SHORT
JP6	OPEN	JP14	SHORT
JP7	OPEN	JP15	SHORT
JP8	OPEN	JP16	SHORT

	BUS	V(I/O)
JP17	SHORT	OPEN
JP18	SHORT	OPEN
JP19	SHORT	OPEN
JP20	SHORT	OPEN
JP21	SHORT	OPEN
JP22	SHORT	OPEN
JP23	SHORT	OPEN
JP24	SHORT	OPEN
JP25	SHORT	OPEN
JP26	SHORT	OPEN

A diagrammatical view
SPB-06CWR

SRC.CORPORATION